

WIESE LANDSIDE CROSS REFERENCE

Make	Model	Description	OEM Number	Wiese Numbers
AC	370/386/387/392	Landside, offset	349819	819W
		Wear Pad for 819W		868W
Case	7000 (18" GP), Blanchat	Landside, offset	T-51968	7000W
	White Bottom	Landside, offset	T-54235	270W
		Landside, offset LH	T-54374	270WL
DMI	Hydra Wide	Inner Plate, medium	33141602	4253W
		Wear Pad	33161601	4256W
Ford	General Purpose (after '58)	Landside, front	107980	980W
		Landside, front LH	108427	980L
		Landside, rear	107981	981W
		Landside, rear LH	108429	981L
	150/151/152	Inner Plate	SBP220379B	379W
		Wear Pad	SBP220919B	919W
IH	Super Chief	Wear Pad	59058C2	058UV
		Wear Pad, LH	1980947C2	058UVL
		Inner Plate	1980672C2	59057
		Inner Plate, LH	1980671C2	59057L
	Plow Chief	Landside, rear	514836	184W
John Deere	HS300-500, SDT, Slat, NU	Inner Plate	AA16493	493W
		Wear Pad for 493W	AA15262 A16495	262W
		Inner Plate, LH	AA16494	494W
		Wear Pad, LH	AA15263 A16496	263W
	NU400/450 Metric	Wear Pad	A27862	862W
		Wear Pad, 3-hole	A45226	47716W
Melroe	987 Series (AC 387)	Landside, all	652543	819W
		Wear Pad (optional)	6521868	868W
	General Purpose	Inner Plate	6526000	6000W
		Wear Pad	6526847	847W
MF	"N" Heavy Duty & High Speed	Landside, all	475153M1 475937M1 475983M1	475W
		Wear Pad		058UV
National David Brown	General Purpose	Landside, medium		HS136
White/Oliver	419/425/619/625/619 Slat	Landside, older	218270B	270W
		Landside, older, LH		270WL
		Landside, newer	1012835	270WA
		Landside, newer, LH		270WAL
		Wear Pad		058UV
		Wear Pad, LH		058UVL

WIESE LANDSIDE CROSS REFERENCE

Make	Model	Description	OEM Number	Wiese Numbers
White/Oliver	549/588/598 Series	Inner Plate	220379B	379W
		Wear Pad	220919B	919W
Wilrich	General Purpose	Inner Plate	14253 215111	4253W
	General Purpose & Deep Till	Wear Pad	14256 215225	4256W
	Deep Till	Inner Plate	20036 20039	20036W
	IH Bottom	Inner Plate	21575	59057
Wear Pad		21576	058UV	